

Remove two screws with  
torx bit and then sepearte  
actuator from caliper.







Insert torx bit and rotate clockwise until you hit point of resistance.



Compress the piston using clamp or other method. It took a good bit of force to get it to slowly retract. Then reinstall parking brake actuator.

