


[BMW F10 535i xDrive Sedan](#) / [Repair Manuals and Technical Data](#) / [51 Body equipment](#) / [51 45 Trim, instrument trim panel](#) /

62 30 005 Removing and installing/replacing trim for Head-Up Display




Special tools required:

- [00 9 317](#)




Lever out trim for Head-Up Display (1) with special tool [00 9 317](#) at mounting points (2).

Feed cover for head-up display (1) in direction of arrow out of instrument panel trim (3) and remove.



Installation note:

Make sure retaining lugs (1) and (2) and sleeve (3) of cover for Head-Up Display (4) are correctly seated.



Note:

Only on F06, F12, F13:

Installation note:

Make sure retaining lugs (1) and (2) are correctly seated on cover for Head-Up Display (3).

For informational purposes only. The information on this website is provided AS-IS with no warranties, express or implied, and is not guaranteed to be error-free, up-to-date or complete. NewTIS and BMW assume no liability for any loss or damage arising from the use or reliance on the information and content on this website. The content on this website is subject to change without notice.